
8 Pin Plug Digital Timer

DIN size W48imesH48mm, Digital timer


■ Features

- •Wide range of the time selection(0.01sec ~ 9999.9 hour)
- ●Power supply: 100-240VAC 50/60Hz, 12-24VDC(Option)
- Memory retention (10 years)
- ●Micro computer built-in
- •8 PIN plug connection type



*Up graded since 2003. 07.

Ordering information



FS4E

Single preset Up/Down Timer

Specifications

Model

Function

| ※A blacked(□) item is upgraded | function. | |
|----------------------------------|-----------|--|
| FS5EI | | |

Indication type Up/Down Timer

| unction | | Single preset op/bown rinner | maleation type op/bown Times |
|---|------------------|---|--|
| Character size | | W4×F | H8mm |
| Power su | ipply | 100-240VAC 50 /60Hz, 12-24VDC (Option) | |
| Allowable | e voltage range | 90 ~ 110% of rated voltage | |
| Power consumption | | Appox. 4.5VA(240VAC 60Hz), Appox. 2.5W(24VDC) | Approx. 3.5VA(240VAC 60Hz), Approx. 2.2W(24VDC) |
| Return time | | Max. 5 | 500ms |
| Min. input RESET input signal width INHIBIT input | | Approx 20ms | |
| Input | RESET input | • NO-voltage input -Impedance a Residual vol | at short-circuit : Max. 470Ω, tage at short-circuit : Max. 1VDC |
| | INHIBIT input | Impedance at open circuit: Min. $100 \mathrm{k}\Omega$ | |
| One-shot output time | | (*) 0.05~ | -5sec |
| | Contact type | Time-limit SPDT(1c) | |
| output | Contact capacity | 250VAC 3A at resistive load | |
| | Mechanical | Min. 10,000,000 times | |
| ife cycle | Electrical | Min. 100,000 times (250VAC 3A resisitive load) | |
| Memory i | retention | 10 years (EEPROM) | |
| Repeat e | rror | | |
| Set error | | Max. ±0.01% ±0.05sec | |
| Voltage e | error | Wax. = 0.01 | // = 0.003cc |
| | ture error | | |
| | n resistance | 100MΩ (at 500VDC) | |
| Dielectric strength | | 2000VAC 50/60Hz for 1 minute | |
| Noise | AC power | $\pm 2 \mathrm{kV}$ the square wave noise(pulse width:1 μ s) by the noise simulator | |
| strength | Be perrer | $\pm 500 \mathrm{V}$ the square wave noise(pulse width:1 μ s) by the noise simulator | |
| Vibration | Mechanical | 0.75mm amplitude at frequency of 10 \sim 55Hz in each of X, Y, Z directions for 1hour | |
| | Malfunction | 0.5 mm amplitude at frequency of $10 \sim 55$ Hz in each of X, Y, Z directions for 10 minutes | |
| Shock | Mechanical | 300m/s² (Approx. 30G) in X, Y, Z directions 3 times | |
| | Malfunction | 100m/s² (Approx. 10G) in X, Y, Z directions 3 times | |
| | temperature | -10 ~ +55 ℃ (at non-freezing status) | |
| Storage temperature | | -25 ~ +65 °C (at non-freezing status) | |
| Ambient humidity | | 35~85%RH | |
| Weight | AC power | Approx. 122g | Approx. 112g |
| | DC power | Approx. 130g | Approx. 120g |

(A) Counter

(B) Timer

(C) Temp.

(D) Power controller

(E) meter

(F) Tacho/ Pulse meter

(G) Display unit

Sensor controller

Proximity

(J) electric sensor

(K) Pressure sensor

Rotary encoder


(M) 5-Phase stepping motor & Driver & Controller

Autonics B - 34


FSE Series

Connections

•FS4E




•FS5EI




■Input connections

OSolid-state input




- ●Transistor ON → INHIBIT, RESET
- •NPN open collector output sensor
- ₩ Above number are number of terminal block.

Contact input



- ●Contact ON → INHIBIT, RESET
- ●Limit S/W, Micro S/W, Relay contact
- •Please use a contact that can function reliable at 5VDC 1mA.


Dimensions




B-35 Autonics

8 Pin Plug Digital Timer

■Selection by DIP switches





*Indication type(FS5EI) has no output mode. (NO. 6, 7, 8 of S/W1)

*Because number 5 of Timer and number 6 of NC are dispensable, the inner selecting switch, DIP S/W is changed from 10pin to 8pin. See former catalog for outmoded items.

●Up/Down mode

| SW1 | Function | |
|--------|-----------|--|
| ON OFF | Down mode | |
| ON OFF | Up mode | |

Memory retention

| SW1 | Function |
|--------|---------------------|
| ON OFF | No memory retention |
| ON OFF | Memory retention |

■Time range mode

| SW 1 | FS4E | FS5EI |
|--------------------------|--------------|-------------------|
| 1 2 3 OFF | 99.99sec | 9999.9sec |
| 1 2 3 OFF | 999.9sec | 99999sec |
| 1 2 3 ON | 9999sec | 9min 59.99sec |
| 1 2 3 ON | 99min 59sec | 99min 59.9sec |
| 1 2 3 ON OFF | 999.9min | 9999.9min |
| 1 2 3 ON II II | 99hour 59min | 9hour 59min 59sec |
| 1 2 3 ON OFF | 999.9hour | 999hour 59sec |
| 0N 2 3 | 9999hour | 9999.9hour |

(A) Counter

(B) Timer

(C) Temp. controller

(D) Power controller

(E) Panel meter

(F) Tacho/ Speed/ Pulse meter

(G) Display unit

(H) Sensor controller

(I) Proximity sensor

(J) Photo electric sensor


(K) Pressure sensor

(L) Rotary encoder

(M) 5-Phase stepping motor & Driver & Controller

Autonics B-36

■Output operation mode (FS4E)



^{*}Time Up: When processing time reaches to setting time.

B-37 Autonics

^{**}Applying reset signal after time up, it will display zero for up mode and time range for down mode(displaying max. value in case of indication type).

8 Pin Plug Digital Timer


■Proper usage

OPreset value

Able to change setting value while it is running but setting value should be higher than previous setting value.

OPower

•The inner circuit voltage starts to rise up for the first 100ms after power on, the input may not work at this time. And also the inner circuit voltage drops down for the last 500ms after power off, the input may not work at this time.




- •Even though the power is applied, and the display does not turn on, please check the reset terminal.
- •Please supply the power within rating power and apply or cut the power quickly to prevent chattering.




OInput signal line

- •Shorten the cable distance between the sensor and this product.
- •Please use shielded wire for input signal.
- •Please wire input signal line separated from power line.



©The reset signal width

It is reset perfectly when the reset signal is applied for max. 20ms regardless of the contact input & solid-state input.



*In case of a contact reset, it is reset perfectly if the ON time of reset signal is applied for max. 20ms even though a chattering is occured.

@Error

If set value is "0000", "Erro" will be displayed.

If set value is changed to non-zero, this function is cancelled. However, the output in the status of Error signal will be OFF.


*The indicator does not have the function of indication.

OReset

Reset has two function, which are memorizing DATA function and resetting output function. When changing an inner selection SW, manual reset or external reset must be held after applying the power by all means. Otherwise it will operate as previous mode. Selecting a reset input/output mode again after applying power, please reset or reset manually, otherwise the previous mode will be operating.

©INHIBIT

- •When you need to check the real operating time, please use INHIBIT function.
- •If you need to stop the time progressing, please use INHIBIT function.



@Environment

Please avoid the following places:

- •Where this product may be damaged by strong impact or vibration.
- •Where there are corrosive gas or flammable gas and water,oil, dust.
- •Where magnetic and electrical noise occurs.
- Where there are High temperature and humidity beyond rated specification.
- •Where there are strong alkalis and acids.
- •Where there are direct rays of sun.

ONoise

We test 2kV, Pulse width 1μ s against Impulse voltage between power terminals and 1kV, pulse width 1μ s at noise simulator against external noise voltage. Please install MP condensor $(0.1 \sim 1\mu\text{F})$ or Oil condensor between power teminals when over Impulse noise voltage occurs.

- When testing dielectric voltage and insulation resistance of the control panel with this unit installed.
 ①Please isolate this unit from the circuit of control panel.
- ②Please make all terminals of this unit shortcircuited.
- •Sudden function stop while it is running (When displaying wrong numbers or nothing)
 In this case, please power off and turn on again.
 This is due to strong noise flows into this product therefore please try to separate inductive load from input signal line of this product or install surge absorber between inductive loads.

(A) Counter

(B) Timer

(C) Temp. controller

(D) Power controller

(E) Panel meter

(F) Tacho/ Speed/ Pulse meter

(G) Display unit

(H) Sensor controller

(I) Proximity

(J) Photo electric sensor

(K) Pressure sensor

(L) Rotary encoder

(M) 5-Phase stepping motor & Driver & Controller

Autonics B-38